


?????????? ??? ?????????? (?????): ?????????? ??? Aspire 5335 5535 5735 5735Z 5737 65

???????????? ??? Aspire 5335 5535 5735 5735Z 5737 6530G



AEZK2700010



?????????? ??? Acer Aspire 5335 5535 5735 5735Z 5737 6530G 6930G 7000 7100 7110 7730 8530 8530G 8920G 8930G 9300 9400 7720 9410 9420 9920 9920G

??????? : ??? ??? ???????

????

???? 1000 ???

[?????? ?????? ?? ??????](#)

????????

????????????? ?????????? ?????????? ??? ??????????: ZK2, ZR6, NSK-AFC2R, NSK-AFE0R, NSK-AFF0R, NSK-AF30R, NSK-AFR0R, NSK-AFU0R, NSK-AFT0R, 9J.N8782.R0R, 9J.N8782.C2R, 9J.N8782.E0R, 9J.N8782.F0R, 9J.N8782.30R, 9J.N8782.U0R, 9J.N8782.T0R, AEZK2700010, AEZR6700010, AEZR6700110, 6037B0029209, PK1306G3A07, MP-07A53SU-920, MP-07A53U4-442, NSK-AFF0R, 9J.N8782.F0R, 9J.N8782.U0R

????????????? ? ?????????????? ?????? ??????????: Acer Aspire 5335 5535 5735 5735Z 5737 6530G 6930G 7000 7100 7110 7730 8530 8530G 8920G 8930G 9300 9400 7720 9410 9420 9920 9920G

Acer Aspire 5737, 5737Z, 6530, 6530G, 7000, 7100, 7104, 7110, 7111, 7112, 7113, 7114, 7116, 9300, 9301, 9302, 9303, 9304, 9305, 9400, 9402, 9403, 9404, 9410, 9411, 9412, 9413, 9420, 9422, 9423, 9424, 9425 Acer TravelMate 5100, 5110, 5600, 5610, 5620, 7320 Acer Extensa 5235, 5235G, 5235Z, 5235ZG, 5635, 5635G, 5635Z, 5635ZG, 7220, 7220G, 7220Z, 7620, 7620G, 7620Z

Acer Extensa 5635 5635G 5635Z 5635ZG 7720 7630 7630G 7630Z 7630ZG 7630EZ ?????????? ??? ?????????? Acer eMachines E528 E728

Fujitsu LifeBook NH570